

TDA080 Parts list

Part Number	Section #	Part Name	Part Number	Section #	Part Name
TDA080P102	614,615	Plastic Sleeve	TDA080P255	2	Feed Roller B
TDA080P110	621	Feet	TDA080P257	2	Feed Roller C
TDA080P202	602	Left Reel Bracket Plate	TDA080P259	2	Feed Roller D
TDA080P203	602	Right Reel Bracket Plate	TDA080P261	2	Feed Roller E
TDA080P204	602	Left Reel Bracket	TDA080P263	1	Sprocket (10T)
TDA080P205	602	Right Reel Bracket	TDA080P264	1	Sprocket (14T)
TDA080P207	1	Rear Panel Assy.	TDA080P265	1	Sprocket (16T)
TDA080P206	616	Front Plate	TDA080P266	1	Sprocket (18T)
TDA080P208	616	Tape Guide	TDA080P267	1	Sprocket (18T)
TDA080P210	618	Right Panel	TDA080P268	3	Motor Sprocket
TDA080P211	621	Base Panel	TDA080P270	3	Sprocket (18T)
TDA080P212	602	Lower Reel Bracket Panel	TDA080P272	2	Roller Shaft A
TDA080P213	616	Control Plate	TDA080P273	2	Roller Shaft B
TDA080P216	614	Left Top Bracket	TDA080P279S	2	Straight Blade
TDA080P217	615	Right Top Bracket	TDA080P279S	2	Serrated Blade
TDA080P218	614	Safety Switch Bracket	TDA080P281	2	Pressing Tape Shaft
TDA080P219	2	Black Frame	TDA080P282	616	Hinge 4
TDA080P220	620	Bottom Inner Plate	TDA080P284	616	Knob Shaft
TDA080P221	2	Inner Middle Panel Assy.	TDA080P301	207,602,614,615	Screw
TDA080P234	1	Feed Detection Wheel	TDA080P302	1,2,3,4,602,614	Screw
TDA080P236	2	Cutter Frame Spring	TDA080P303	4,602,618	Nut
TDA080P237	2	Roller Spring	TDA080P305	616	Screw
TDA080P242	603	Blade Roller	TDA080P306	616	Nut
TDA080P243	2	Slide Pin (Long)	TDA080P307	618	Screw
TDA080P244	2	Slide Pin (Short)	TDA080P308	620	Screw
TDA080P250	3	Drive Chain	TDA080P309	620	Lock Washer
TDA080P251	1	Feed Chain #1	TDA080P310	2,4,221,603,620,621	Nut
TDA080P252	1	Feed Chain #2	TDA080P312	603	Screw
TDA080P253	2	Feed Roller A	TDA080P313	221,603,614	Screw

TDA080 Parts list

Part Number	Section #	Part Name	Part Number	Section #	Part Name
TDA080P314	1,3,4	Screw	TDA080P411	620	Transformer
TDA080P315	1	Screw	TDA080P413	616	Mode Button
TDA080P316	1,616	Screw	TDA080P414	207	Power Inlet
TDA080P317	1,3	E-ring	TDA080P415	616	Interval Switch
TDA080P318	1,3	E-ring	TDA080P416	616	Advance Button
TDA080P319	1,3	Washer	TDA080P417	616	Cut Button
TDA080P320	1	Wheel Sleeve	TDA080P418	616	Power Switch
TDA080P321	1,3,4	Screw	TDA080P420	2	Middle Frame
TDA080P322	3	Screw	TDA080P601	2	Reel Holder Assy.
TDA080P324	2	Screw	TDA080P602	2	Tape Holder Assy.
TDA080P325	2	Washer	TDA080P603	2	Blade Holder Assy.
TDA080P326	4	Plastic Washer	TDA080P604	618	Top Door
TDA080P327	4	Screw	TDA080P605	3	Detection Wheel Assy.
TDA080P328	4	Cable Hold Down	TDA080P606	615	Right Inner Panel
TDA080P329	3	Screw	TDA080P607	2	Roller Support
TDA080P330	3	E-ring	TDA080P608	614	Left Inner Panel
TDA080P331	1	Screw	TDA080P609	3	Feed Roller Gear Assy.
TDA080P332	621	Screw	TDA080P610	1	Feed Roller Gear Assy.
TDA080P352	207	Fuse	TDA080P614	1	Left Inner Panel Assy.
TDA080P353	620	Switch	TDA080P615	3	Right Inner Panel Assy.
TDA080P401	2	Motor & Gearbox	TDA080P616	4	Feed Roller Gear Assy.
TDA080P402	2	Solenoid	TDA080P617	616	Switch Fixer Plate
TDA080P403C	4	Main PCB	TDA080P618	3	Right Panel Assy.
TDA080P404	616	Control PCB	TDA080P620	4	Inner Plate Assy.
TDA080P405	1	Power Cord	TDA080P621	4	Base Assy.
TDA080P406-1	1	Encoder Right			
TDA080P406-2	3	Encoder Left			
TDA0800P407	614	Safety Switch			
TDA080P408	207	Foot Switch			